

Homework4

Astro 500 Cooper

Elijah Bernstein-

1

The magnification factor is given by

$$w_{\theta} = \frac{f_2}{f_1} w$$

where w_{θ} is the reimaged spatial width, and w is the physical slit width. f_2 is the detector focal length and f_1 is the collimator focal length. The magnification factor is then

$$\frac{f_2}{f_1} = \frac{f/1.33}{f/3.32} = 1.33/3.32 = 0.4$$

2

$$w = 300 \mu\text{m}$$

$$w_{\theta} = f_2/f_1 w$$

$$w_{\theta} = 0.4 \times 300 \mu\text{m}$$

$$w_{\theta} = 120.2 \mu\text{m} = 8 \text{ pix}$$

3

$$\frac{f_1}{D_1} = 3.32$$

$$D_1 = 115 \text{ mm}$$

$$f_1 = 3.32 D_1 = 381.8 \text{ mm}$$

and in Littrow $D_1 = D_2$

$$f_2 = 1.33 D_2 = 152.5 \text{ mm}$$

4

$\alpha = \beta = 100 \text{ deg}$ for Littrow. $\lambda_c = 653 \text{ nm}$. Given $m = 1$
the grating equation gives

$$\lambda = \sigma[\sin\alpha + \sin\beta]$$

thus the separation σ is

$$\frac{[\sin\alpha + \sin\beta]}{\lambda} = \frac{1}{\sigma}$$

$$\frac{1}{\sigma} = 2 \sin\left(100 \deg \frac{\pi}{180}\right) [653 \times 10^{-3} \text{ mm}]^{-1}$$

$$\frac{1}{\sigma} = 3016 \text{ mm}^{-1}$$

5

$$\gamma = \frac{d\beta}{d\lambda}$$

$$\gamma = [\sigma \cos\beta]^{-1} [\text{mm}^{-1}]$$

$$\gamma = 0.0019 \text{ mm}^{-1}$$

6

linear dispersion in Å/mm is given by

$$\frac{d\lambda}{dx} = \frac{\sigma \cos\beta}{mf_2} \lambda_{\text{pix}}$$

$$\frac{d\lambda}{dx} = \left[\frac{1}{3016} \text{ mm} \times 10^7 \frac{\text{\AA}}{\text{mm}} \right] \cos\left(100 \deg \frac{\pi}{180}\right) [152.5 \text{ mm}]^{-1} \left[15 \times 10^{-3} \frac{\text{mm}}{\text{pix}} \right]$$

$$\frac{d\lambda}{dx} = 3.77 \frac{\text{\AA}}{\text{mm}} = 0.057 \frac{\text{\AA}}{\text{pix}} = 3.77 \times 10^{-7}$$

7

The anamorphic magnification is 1 for Littrow spectrographs.

8

The spectral resolution, R , of the system is given by

$$R = \frac{\lambda}{d\lambda}$$

which in Littrow is

$$R = (f_1/w) 2 \tan\alpha$$

where w is the physical slit width and f_1 is the collimator focal length.

$$R = \left(\frac{381.8 \text{ mm} \times 10^3 \frac{\mu\text{m}}{\text{mm}}}{300 \mu\text{m}} \right) 2 \tan\left(100 \deg \frac{\pi}{180}\right)$$

$$R = 14,435$$

9a

A resolution element is the reimaged slit width. We have 8 pixels per reimaged slit width $w_{\theta'}$.

$$d\lambda = \frac{w_{\theta'}}{dl/d\lambda} = \frac{8 \text{ pix}}{\left(0.057 \frac{\text{\AA}}{\text{mm}}\right)^{-1}} = 0.0456 \text{ nm}$$

$$R = \frac{\lambda}{d\lambda} = \frac{653 \text{ nm}}{0.0456 \text{ nm}} = 14,320$$

9b

The resolution element determines the maximum spectral resolution an instrument can have. With more pixels across the resolution element we could have a higher spectral resolution.

9c

To correctly Nyquist sample the slit, we need two pixels. We can bin by four pixels since our reimaged slit width is 8 pixels.